




Calibre 3135



Base Calibre 3135



- Ø28.5mm
- Train: 28.800
- Automatic
- Calendar
- Centre second
- Shock Proof
- 31 Jewels

	N°	Idem calibre	English
	4494	2030	In-setting spring for escape wheel-upper /lower
	5021	3035	Roller
	95019-1	3035	Shock absorber for balance-lower
	95019-2	3035	In-setting for balance-upper / lower
	95019-3	3035	Cap jewel for balance-upper / lower
	95019-4	3035	In-setting spring for balance-upper /lower
	95067	3035	Jewel for: • Reversing wheel-upper /lower • Driving wheel for ratchet wheel-upper
	2130-0913-2	2130	Cap jewel for escape wheel-upper /lower



	N°	English
	3135-0913	In-setting for escape wheel- upper /lower
	3135-0915	Shock absorber for balance- upper
	3135-0945	Regulating friction-spring for balance bridge
	3135-100	Main plate
	3135-105	Barrel bridge
	3135-110	Train wheel bridge
	3135-115	Pallet bridge
	3135-118	Balance guard
	3135-120	Balance bridge

	N°	English
	3135-125	Minute pinion bridge
	3135-130	Winding bridge
	3135-135	Automatic device lower bridge
	3135-140	Automatic device bridge, upper
	3135-145	Automatic device module
	3135-201	Winding stem
	3135-204	Winding pinion
	3135-205	Sliding pinion
	3135-210	Crown wheel
	3135-211	Crown wheel core

	N°	English
	3135-212	Core for intermediate crown wheel
	3135-213	Intermediate crown wheel
	3135-217	Yoke for sliding gear
	3135-220	Setting-lever
	3135-225	Setting-lever spring
	3135-230	Setting-lever jumper
	3135-240	Yoke for sliding pinion
	3135-241	Yoke spring
	3135-245	Balance stop spring
	3135-250	Setting-wheel
	3135-260	Minute wheel
	3135-266	Yoke for setting-wheel
	3135-268	Mechanism cover, mounted

	N°	English
	3135-270	Cannon pinion ht. 2.86mm
 	3135-280	Hour wheel
	3135-300	Click
	3135-301	Click spring
	3135-305	Ratchet wheel
	3135-307	Barrel arbor
	3135-311	Mainspring, standard strength
	3135-311-1	Mainspring, weak strength
	3135-315	Barrel complete with mainspring
 	3135-330	Great wheel
	3135-335	Minute pinion with cannon pinion
 	3135-340	Third wheel
 	3135-360	Second wheel


	N°	English
 	3135-410	Escape wheel
	3135-419	Pallet staff
	3135-421	Pallet fork
	3135-429	Balance staff
	3135-432	Balance with Breguet hairspring, timed
	3135-450	Stud support
	3135-451	Bridle for stud support
 	3135-510	Driving wheel for ratchet wheel
 	3135-540	Reversing wheel, mounted
	3135-550	Pinion for oscillating weight
		Spring-clip for oscillating weight:
	3135-560-1	• 0.18mm
	3135-560-2	• 0.160mm
	3135-560-3	• 0.200mm
	3135-561	Bridle for spring-clip

	N°	English
	3135-568	Axle for oscillating weight
	3135-570	Oscillating weight
	3135-600	Date indicator seating
	3135-614	Date jumper
	3135-623	Date finger
	3135-625	Date wheel, mounted
	3135-633	Yoke for cam
	3135-635	Cam yoke spring
	3135-639	Intermediate date corrector wheel

	N°	English
	3135-645	Date corrector
 	3135-670	Intermediate date wheel
  	3135-5000	Set of screws
	3135-5013	Dial screw
	3135-5044	Minute wheel stud
	3135-5100	Screw for case
	3135-5110	Screw for: • Balance guard • Balance bridge • Winding bridge • Automatic device lower bridge • Automatic device bridge, upper • Barrel bridge • Train wheel bridge
	3135-5115	Screw for: • Bridle of spring-clip • Bridle for stud holder • Click • Setting-lever spring • Setting-lever jumper • Minute pinion bridge • Pallet bridge • Mechanism cover

	N°	English
	3135-5120	Regulating nut for balance bridge height adjustment
	3135-5210	Screw for: • Crown wheel • Ratchet wheel
	3135-5213	Screw for intermediate crown wheel
	3135-5452	Screw for hairspring clamp
	3135-5600	Screw for date indicator seating
	3135-5625	Screw for date wheel
	3135-7115	Tapped foot for pallet bridge
	3135-7120	Tapped foot of balance bridge
	3135-7240	Yoke stud
	3135-7250	Setting-wheel ring
	3135-7600	Foot for date indicator seating
	3135-7625	Tapped foot for date wheel

	N°	English
	3135-7635	Stud for came yoke spring
	3135-9310	Jewel for barrel arbor-upper
	3135-9311	Jewel for barrel arbor-lower
	3135-9319	Bush for minute pinion-lower
	3135-9330	Jewel for great wheel-upper /lower
	3135-9335	In-setting for minute pinion-upper
	3135-9340	Jewel for third wheel-upper /lower
	3135-9360	Jewel for second wheel-upper
	3135-9421	Jewel for pallet fork-upper /lower
	3135-9510	Jewel for driving wheel for ratchet wheel support
	3135-9511	Jewel for driving wheel for ratchet wheel-lower
	3135-9570	Jewel for oscillating weight-upper
	3135-9571	Jewel for oscillating weight-lower
	3135-9633	Jewel for cam yoke

	N°	English
⑧	3135-9670	Jewel for intermediate date wheel-upper /lower
		Date indicator,
	3135-16100	champagne
	3135-16101	• champagne, arabic/persian
	3135-16102	• champagne, chinese
	3135-16103	• champagne, persian
	3135-16104	• champagne, modern chinese
		Date indicator,
	3135-16200	• white
	3135-16201	• white, arabic/persian
	3135-16202	• white, chinese
	3135-16203	• white, persian
	3135-16204	• white, modern chinese
	3135-16205	• white, red numbers
	3135-16206	• white, even numbers black, odd numbers red
	3186-432	Balance with PARACHROM Breguet hairspring, timed Depends on model reference, see R20